

Nelson-Rigg Route 1 Road Trip Saddlebag Fitment

Fitments Confirmed Through 2024 Models. Please visit our website for updates.

All hardware (bolts, washers and spacers) are provided for installation on below vehicles.

Motorcycle Brand	Years	Hardware Included	Spacers to be used	Bolts to be used
BMW				
R18	2020 - 2024	Yes	Qty 4: M8 x 6mm Spacers	Qty 4: x 8M - 1.25 x 25mm
Honda				
Rebel 500	2017 to Current	Yes	Qty 4: M8 x 6mm Spacers	Qty 4: M8 - 1.25 x 25mm
Rebel 300	2017 to Current	Yes	Qty 4: M8 x 6mm Spacers	Qty 4: M8 - 1.25 x 25mm
Harley Davidson				
Blackline - FXS *	2010-2012	Yes	Vehicles use factory bolts only	
Night Train - FXSTB	2000-2009	Yes		
Springer - FXSTS	2000-2007	Yes		
Cross Bones - FLSTSB	2008-2011	Yes		
Fat Boy - FLSTF	2000-2017	Yes		
Fat Boy - FLFB	2018 to Current	Yes		
Deluxe - FLSTN	2005-2017	Yes		
Deluxe - FLDE	2018 to Current	Yes		
Breakout - FXSB	2013-2017	Yes		
Breakout - FXBR	2018 to Current	Yes		
Standard - FXST	2000-15 & 2020 - 2023	Yes		
Standard Custom - FXSTC	2007-11 & 2014	Yes		
Street Bob - FXBB	2018 to Current	Yes		
Low Rider - FXDL *	2000-17	Yes		
Wide Glide - FXDWG *	2000-17	Yes		
Street Bob - FXDB *	2006-17	Yes		
Super Glide - FX *	2000-2012	Yes		
Super Glide Custom - FXD *	2005-2015	Yes		
Softail Slim - FLS	2012-17	Yes	Vehicles use factory bolts with included M10 or 1.5mm washer	
Softail Slim - FLSL	2018 - 2021	Yes		
Low Rider - FXLR	2018 to Current	Yes		
Indian				
Scout & Scout Sixty**	2015 to 2023	Yes	Qty 4: M8 x 6mm Spacers	Qty 4: M8 - 1.25 x 25mm
Kawasaki				
Vulcan 900 Classic	2009 to Current	Yes	All vehicles use factory bolts	
Vulcan 900 Custom	2010 to Current	Yes		
Kawasaki Vulcan S	2015 to Current	Yes		
Eliminator	2023 to Current	Yes		
Suzuki				
C50	2005 to Current	Yes	Qty 4: M8 x 6mm Spacers	Qty4: 8M - 1.25 x 60mm
M109R	2006 to Current	Yes	Qty 4: M8 x 6mm Spacers	Qty2: 8M - 1.25 x 80mm Qty2: 8M - 1.25 x 60mm
Boulevard M50	2010 to Current	Yes	Qty 4: M8 x 6mm Spacers	Qty2: 8M - 1.25 x 80mm Qty2: 8M - 1.25 x 60mm

*Relocate Turn Signals

** (not Bobber or Rogue)

Below vehicles require some additional hardware to mount.

Most can be found at local hardware stores or on-line.

Motorcycle Brand	Years	Hardware Included	Spacers M10 and 1/4" not included	Bolts needed to be purchased separately
Honda				
Shadow Aero	2006 to 2023	No	Not Needed	QTY 4: M10 - 1.25 x 45mm
Shadow Phantom	2024 to Current	No	Qty 4: M8 x 12mm Spacers	Qty 2: M10 - 1.25 x 50mm QTY 2: M10 - 1.25 x 40mm QTY 4: M10 Washers
VTX 1300	2003 to 2009	No	Qty 2: M8 x 12mm Spacers Qty 2: M10 x 12mm Spacers	Qty 2: M8 - 1.25 x 35mm Qty 2: M10 - 1.25 x 40mm QTY 2: M10 Washers
VLX 600 Shadow	1993 to 2007	No	Qty 2: M8 x 12mm Spacers Qty 2: M8 x 6mm Spacers	Qty 4: M8 - 1.25 x 70mm
Harley Davidson				
Fat Bob - FXDF	2008-17	No	Qty 4: 1/4" Spacers	Qty 4: 3/8"-16 x 1.25"
Suzuki				
Volusia 800	2001 to 2007	No	Qty 4: M8 x 12mm Spacers	Qty 2: M8 - 1.25 x 70mm
Triumph				
Speedmaster	2004 - 2016	No	Qty 4: M8 x 12mm Spacers	Qty 2: M8 - 1.25 x 45mm
Yamaha				
Stryker	2010 to 2016	No	Qty 4: M8 x 12mm Spacers	Qty 2: M8 - 1.25 x 50mm Qty 2: M8 - 1.25 x 45mm
Roadstar Warrior	2002 to 2010	No	Qty 4: M8 x 12mm Spacers	Qty 4: M8 - 1.25 x 40mm
V-star 1100 Classic	1998 to 2008	No	Qty 4: M8 x 12mm Spacers	Qty 4: M8 - 1.25 x 35mm
V-Star 650 Classic	1998 to 2008	No	Qty 4: M8 x 6mm Spacers	Qty 4: M8 - 1.25 x 40mm
Bolt***	2013 to 2023	No	Qty 4: M8 x 12mm Spacers Qty 2: M8 x 6mm Spacers	Qty 4: M8 - 1.25 x 70mm

***w/o Piggyback Shock Reservoir